

Double Swing Standard - Operation

VENTILATION:


There are three stages of ventilation available on the Blairs of Scotland Double Swing. These stages are described in Figures one, two and three.



1. Open handles and latch into slot in keeper.



2. Open handles and push sash forward until it locates safety restrictor.



3. Press release catch inside track on the left hand side and sash will open up for further ventilation.

CLEANING:

The hinging mechanism of the Double Swing allows both sashes to be reversed for easy cleaning without fouling blinds or curtains. This procedure is straightforward and is described in Fig. 4



4. Push bottom of sash to its maximum travel on the outward position (bypassing restrictors), once this has been reached pull top of sash downwards until it locates in the reverse locking position. (Cleaning position) Release catch and reverse procedure to bring sash back to the closed position. Operate both sashes using the same procedure.

MAINTENANCE:

- a) When painting in and around windows, care should be taken to ensure no paint covers weather-strip or hardware.
- b) Slight lubrication should be carried out on fittings, when necessary, with acid free oil.