

## Enhanced Casement Side Hung - Operation

### Ventilation:

There are three stages of ventilation available on the Blairs of Scotland Side Hung. These stages are described in Figures 1 & 2.




1. *Open handles and latch into slot in keeper.*



2. *Open handles and push sash forward until it locates safety restrictor.*

### Cleaning:

The hinging mechanism of the Blairs of Scotland Side Hung allows the sash to be reversed for easy cleaning without fouling blinds or curtains. This procedure is straightforward and is described in Fig 3.



3. *Press the release catch on the safety restrictor, (if fitted) and push sash forward until it has reached its maximum on the outward position (cleaning position). Reach through between the frame jamb and sash stile to clean the glass area. To complete the operation, bring sash back to the closed position.*

### Maintenance:

- a) When painting in and around windows, care should be taken to ensure no paint covers weather-strip or hardware.
- b) Slight lubrication should be carried out on fittings, when necessary, with acid free oil.