

## Enhanced Casement Canopy Action - Operation

### Ventilation:


There are three stages of ventilation available on the Blairs of Scotland Enhanced Casement. These stages are described in Figures 1-3.



*1. Open handles and latch into slot in keeper.*



*2. Open handles and push sash forward until it locates safety restrictor.*



*3. For further ventilation beyond the safety restrictor. Press release catch inside track on the left hand side and sash will open up for further ventilation.*

### Cleaning:

The hinging mechanism of the Blairs of Scotland Enhanced Casement allows the sash to be reversed for easy cleaning without fouling blinds or curtains. This procedure is straightforward and is described in Fig 4.



*4. Push bottom of sash to its maximum travel on the outward position (bypassing restrictors), once this has been reached pull top of sash downwards until it locates in the reverse locking position. (Cleaning position) Release catch and reverse procedure to bring sash back to the closed position.*

**Maintenance:**

- a) When painting in and around windows, care should be taken to ensure no paint covers weather-strip or hardware.
- b) Slight lubrication should be carried out on fittings, when necessary, with acid free oil.